

Easy Clean UV Maintenance

BRIGHT / SUPREME / DURABLE

Bright, Supreme, Durable are manufactured with a specially invented UV-cured Easy Clean UV PUR that provides innovative maintenance advantages and options. This PUR doesn't require waxing and polish because this unique surface treatment technique prevents contaminants from penetration into the wear layer. To ensure these products retain their original appearance for as long as possible, Kenbrock Flooring recommends:

- Protecting new flooring against damage during construction with plain undyed kraft paper or wood panels
- Walk-off mats be installed at entry points to the building to limit the amount of wet and dry soiling. If maintained correctly, these mats should limit the transfer of grit and grime, making the daily cleaning and maintenance even easier.

Initial Maintenance (Immediately after Installation)

1. Ensure all adhesive residue is removed from the surface of the flooring. Mineral spirits is approved for removing dried adhesive.
2. Sweep or vacuum the floor to remove all surface soil, dirt, sand and grit.
3. Depending on the level of site soiling after the installation is complete, it may be necessary to scrub the floor clean prior to adopting the daily maintenance regime. Please choose the suitable option below.
 - a. Mop with diluted neutral cleaner/detergent, rinse with clean water and allow it to dry.
 - b. Scrub the floor with diluted neutral detergent using a standard-speed rotary scrubber (150 – 250 rpm) or a scrubber dryer
 - c. (Combination machine) fitted with a red pad. Pick up solution with a wet vac. Rinse with clean water and allow to dry.
 - d. Finally buff with a rotary machine capable of 200 – 1000 rpm, fitted with a beige pad.

Daily / Weekly / As Needed / Maintenance

To maintain your new floor's original appearance, it is recommended to follow a routine maintenance program.

Option 1 – Non Mechanical Method

1. Sweep, dust mop or vacuum the floor to remove all dust, dirt and grit.
2. Mop the floor with a clean water dampened mop head.
3. For surface grime not removed by water-cleaning, hand spray tough spots with a neutral cleaner/detergent, scrub as needed, and rinse with clean water and allow to dry.

Option 2 – Mechanical Method

1. Sweep, dust mop or vacuum the floor to remove all dust, dirt and grit.
2. Scrub with diluted neutral cleaner/detergent using a standard-speed (150 – 250 rpm) rotary machine fitted with a red pad.
3. Pick up solution with a wet vac.
4. Rinse with clean water and allow to dry.

Do not apply polish or wax on Easy Clean UV treated surface.

Periodic Maintenance

1. Mop on a diluted neutral cleaner/detergent solution, wait about 5 to 15 minutes.
2. Scrub the floor using a 150 – 250 rpm scrubber equipped with red pad or similar brush.
3. Pick up dirty solution with a wet vac not allowing it to dry on the floor.
4. Rinse the cleaned floor with clean water, change rinse water as often as needed, until the water remains clear.
5. After final rinsing, allow floor to dry completely.
6. Clean floor can now be buffed with a rotary machine capable of 200 – 1000 rpm, fitted with a beige pad or similar brush.

Products with Easy Clean UV don't require waxing and polish, however, if waxing and polish is desired for extra protection in heavy traffic areas, follow these recommendations.

The flooring polish on this PUR requires stripping process in advance. Please follow the guide below.

Flooring Polish

1. Follow steps 1 – 6 in periodical maintenance guide, but use Stripper instead of detergent solution in step 1, and choose the Brown pad or equivalent scrub brush instead of Red pad for stripping process in step 2. (Stripper with PH 12-14 diluted 1:3~1:5 with water is recommendable, for the detailed information, please contact to the local stripper manufacturers.)
2. Apply the floor polish as recommended by the polish manufacturer.
3. Allow polish to completely dry between coats (minimum 30 minutes dry time).
4. Apply additional coats, 3 – 4 of a high quality acrylic floor polish, depending on level of traffic.
5. Buff with a rotary machine capable of 200 –1,000 rpm, fitted with a white or beige pad or similar brush.

Precautions

1. When conducting the routine cleaning work, do not completely remove Easy Clean UV(PUR), but for polishing on it, remove the existing PUR.
2. Apply only the recommended amount of neutral cleaner/detergent and polish.