

To maintain the good looks of your Gerflor Primetex flooring with minimal effort follow these guidelines.

#### CARE AND PROTECTION

- These products have an embossed protective polyurethane surface treatment applied to the product during the manufacturing process. It is therefore usually not necessary to seal or polish these products over their complete lifetime, greatly reducing the maintenance costs overall.
- Use weight dispersing aids under heavy furniture.
- Use mats in doorways to reduce the amount of dirt and grit which could damage the new flooring.
- **Rubber leaves indelible stains on vinyl flooring.** Avoid placing waxed or rubber products in prolonged contact with the Primetex floor.

#### INITIAL CLEAN

- Remove loose dirt and debris from the newly installed floor using broom or vacuum. Ensure all adhesive residues are removed with due regard to supplier's recommendations. Do not use high abrasive pads or scourers.
- Wash floor with a damp mop using a neutral pH7 floor cleaning detergent with water. Ensure all detergent residues are rinsed and removed from the floor.

#### MAINTENANCE

- For everyday maintenance use a soft broom or damp mop.
- To clean Primetex use a neutral pH7 floor cleaning detergent with water and rinse thoroughly.

#### STAINS

- Clean up any potential stains immediately; don't let them become a problem.
- Most stains can be removed using a damp cloth and eucalyptus oil.
- Solvents and ammonia based cleaners will damage your floor. Do not use these products.

If you have any queries about the care and maintenance of your Primetex floor, please contact Gerflor customer service.

